

Best Management Practices (BMPs): *Erosion*

LAND AND DRAINAGE ALTERATION PROGRAM (LDAP)

Residential Construction Entrance/Exit

Protect adjoining roads and waterways from vehicular tracking of sediment off of the site.

INSTALLATION STEPS:

- 1) Install as soon as vehicle traffic will be entering and exiting the site.
- 2) Install geotextile fabric over subgrade prior to placing crushed rock.
- 3) Use $\frac{3}{4}$ minus clean rock or larger.
- 4) Construct entrance a minimum of 20 feet wide and extend from the roadway to the foundation or a minimum of 20'.
- 5) Maintain a minimum 8" rock depth. Monitor for tracking of sediment offsite and make corrections as necessary.

For more BMP examples, see Springfield's "Engineering Design Standards and Procedures Manual" Chapter 8.

